

Forschungsinstitut für Pigmente und Lacke e.V.

Allmandring 37, D-70569 Stuttgart

Tel.: 0711/68780-0, Fax: 0711/68780-79

e-Mail: fpl@fpl.uni-stuttgart.de

Prüfbericht – Nr.: AT 097/04

Abteilung Anwendungstechnik

Seite 1 von 4

Test Report

Customer:

JUB Kemična industrija d.d.

1262 Dol pri Ljubljani 28

Slowenien

Date of commission:

22.09.2004

Sample taking:

by the customer

Storing of sample

material:

All samples are stored 25 month after delivering the results to the customer, unless the sample material was used up or destroyed by chemical reaction or any other agreements were

made.

Item of contract:

Interior emulsion wall paint :

Jupol Latex - Matt

- Jupol Latex - Seidenmatt

Jupol Latex - Saten

Purpose:

Determination of the resistance of interior wall paints

to disinfectants

Beginning of tests:

28.09.2004

End of tests:

01.12.2004

Designation of the laboratory:

Application technique



Forschungsinstitut für Pigmente und Lacke e.V.

Allmandring 37, D-70569 Stuttgart

Tel.: 0711/68780-0, Fax: 0711/68780-79

e-Mail: fpl@fpl.uni-stuttgart.de

Prüfbericht – Nr.: AT 097/04 Abteilung Anwendungstechnik

Seite 2 von 4

Enclosures:

enclosure 1-6

Test method:

Determination of the resistance of interior wall paints to 4 disinfectants (ISO 2812-1)

Method 2:

The coatings were charged with compressed paper-board pads, soaked with the disinfectants. The pads were covered with watch glasses

Test temperature: 23 °C ± 2 °C

disinfectants	concentration [%]	test period (h)			
Hexaquart S (Braun)	1,00	1,0			
Surfanios Citron (Anios)	0,25	4,0			
Incidur (Ecolab)	0,50 0,75 3,00	4,0 1,0 1,0			
Kohrsolin FF (Bode Chemie)	0,75 1,00 3,00	1,0 0,5 0,5			

disinfectants	composition (active agents)
Hexaquart S	Didecyldimethylammoniumchlorid, Benzalkoniumchlorid
Surfanios Citron	Didecyldimethylammoniumchlorid, Aminosäurehydrochlorid
Incidur	Glyoxal, Glutaral
Kohrsolin FF	Glutaraldehyd, Benzalkoniumchlorid, Didecyldimethylammoniumchlorid

551	Forschungsinstitut für Pigmente und Lacke e.V.					
IDI	Allmandring 37, D-70569 Stuttgart Tel.: 0711/68780-0, Fax: 0711/68780-79					
-	e-Mail: fpl@fpl.uni-stuttgart.de					
Prüfbericht – Nr.: AT 097/04	Abteilung Anwendungstechnik	Seite 3 von 4				

Test result:

As can be seen in enclosure 1 to 6, there were no changes on the coating surface of **Jupol Latex** –**Matt** after stressing with the different disinfectants.

Jupol Latex -Seidenmatt showed small blisters directly after the influence of the disinfectants Hexaquart S, Surfanios Citron and Incidur (3 % ig, 1 h), which disappeared 24 hours after the test.

24 hours after the test **Jupol Latex** –**Seidenmatt** showed either no changes of the coating surface or only small changes with the values of 0-1 to 1 on a relative scale from 0 to 5. The changes can be described as follows:

- Imprints of the pad structure and the rim of the pad
- loss of gloss on the stressed surface

These small changes can be seen in most cases only under artificial illumination.

Jupol Latex - Saten showed directly and 24 hours after the influence of the disinfectants small changes of the surface of the values 0-1 to 1-2. The changes are similar to that on Jupol Latex —Seidenmatt and can be seen also in most cases only under artificial illumination.

Comments*:

The test results refer to the samples, only. This test report may not be published (even not in parts) without the allowance of the FPL.

^{*} The comments are an additional interpretation (opinion) beyond the test methods.



Forschungsinstitut für Pigmente und Lacke e.V.

Allmandring 37, D-70569 Stuttgart

Tel.: 0711/68780-0, Fax: 0711/68780-79

e-Mail: fpl@fpl.uni-stuttgart.de

Prüfbericht – Nr.: AT 097/04 Abteilung Anwendungstechnik

Seite 4 von 4

Stuttgart, 22.12.2004

i.A

K. GasznerApplication technique

E. Fixle

i. A.

E. Fischer tester

Resistance of 3 "Latex" paints to 4 disinfectants at room temperature - assessment directly after the test

a) Assessm	a) Assessment according to EN ISO 4628-1:2003(D)									
value	intensity of the change	value	intensity of the change							
0	no visible change	3	medium, distinctly visible change							
1	very small visible change	4	strong visible change							
2	small visible change	5	very strong visible change							

b) Assessment according to EN ISO 4628-2: evaluation of blistering

disinfectant	sample	assessment after [h]	Jupol Latex - Matt value	sample	Jupol Latex - Seidenmatt value	sample		Jupol Latex - Saten value
Hexaquart S	4/1/a	at once	0	5/1/a	m5/g2	6/1/a	1	(artificial illumination and daylight)
(1%)	4/1/b	at once	0	5/1/b	m5/g2	6/1/b	1	(artificial illumination and daylight)
1h test period	4/1/c	at once	0	5/1/c	m5/g2	6/1/c	1	(artificial illumination and daylight)
Surfanios	4/2/a	at once	0	5/2/a	m5/g2(-3)	6/2/a	1-2	(artificial illumination and daylight)
(0,25%)	4/2/b	at once	0	5/2/b	m5/g2	6/2/b	1-2	(artificial illumination and daylight)
4h test period	4/2/c	at once	0	5/2/c	m5/g2(-3)	6/2/c	1-2	(artificial illumination and daylight)

Resistance of 3 "Latex" paints to 4 disinfectants at room temperature - assessment 24 hours after the test

a) assessm	a) assessment according to EN ISO 4628-1:2003(D)									
value	intensity of the change	value	intensity of the change							
0	no visible change	3	medium, distinctly visible change							
1	very small visible change	4	strong visible change							
2	small visible change	5	very strong visible change							

disinfectant	sample	assessment after [h]	Jupol Latex - Matt value	sample		Jupol Latex - Seidenmatt value			- Saten value
Hexaquart S	4/1/a	24	0	5/1/a		0	6/1/a	0-1	(artificial illumination)
(1,00%)	4/1/b	24	0	5/1/b		0	6/1/b	0-1	(artificial illumination)
1h test period	4/1/c	24	0	5/1/c		0	6/1/c	0-1	(artificial illumination)
Surfanios	4/2/a	24	0	5/2/a	0-1	(artificial illumination)	6/2/a	1-2	(artificial illumination)
(0,25%)	4/2/b	24	0	5/2/b	0-1	(artificial illumination)	6/2/b	1-2	(artificial illumination)
4h test period	4/2/c	24	0	5/2/c	0-1	(artificial illumination)	6/2/c	1-2	(artificial illumination)

AT 097 / 04 enclosure 3

Resistance of 3 "Latex" paints to 4 disinfectants at room temperature - assessment directly after the test

a) assessment	a) assessment according to EN ISO 4628-1:2003(D)									
value	intensity of the change	value	intensity of the change							
0	no visible change	3	medium, distinctly visible change							
1	very small visible change	4 strong visible change								
2	small visible change	5	very strong visible change							

b) Assessment according to EN ISO 4628-2: evaluation of blistering

disinfectant		assessment	Jupol Latex		Jupol Latex		12		Jupol Latex	
	sample	after [h]	- Matt value	sample		- Seidenmatt value	sample	- Saten value		
Incidur	4/3a/a	at once	0	5/3a/a	1	(artificial illumination)	6/3a/a	1	(artificial illumination)	
a) 0,50%	4/3a/b	at once	0	5/3a/b	1	(artificial illumination)	6/3a/b	1	(artificial illumination)	
4h test period	4/3a1/c	at once	0	5/3a/c	1	(artificial illumination)	6/3a/c	1	(artificial illumination)	
Incidur	4/3b/a	at once	0	5/3b/a	1	(artificial illumination)	6/3b/a	1	(artificial illumination)	
b) 0,75%	4/3b/b	at once	0	5/3b/b	1	(artificial illumination)	6/3b/b	1	(artificial illumination)	
1h test period	4/3b/c	at once	0	5/3b/c	1	(artificial illumination)	6/3b/c	1	(artificial illumination)	
Incidur	4/3c/a	at once	0	5/3c/a		m5/g2	6/3c/a	1	(artificial illumination)	
c) 3,00%	4/3c/b	at once	0	5/3c/b		m5/g2	6/3c/b	1	(artificial illumination)	
1h test period	4/3c/c	at once	0	5/3c/c		m5/g2	6/3c/c	1	(artificial illumination)	

Resistance of 3 "Latex" paints to 4 disinfectants at room temperature - assessment 24 hours after the test

a) assessment according to EN ISO 4628-1:2003(D)									
value	intensity of the change	value	intensity of the change						
0	no visible change	3	medium, distinctly visible change						
1	very small visible change	4	strong visible change						
2	small visible change	5	very strong visible change						

disinfectant	sample	assessment after [h]	Jupol Latex - Matt value	sample		Jupol Latex - Seidenmatt value	sample		Jupol Latex - Saten value
Incidur	4/3a/a	24	0	5/3a/a	1	(artificial illumination)	6/3a/a	0-1	(artificial illumination)
a) 0,50%	4/3a/b	24	0	5/3a/b	1	(artificial illumination)	6/3a/b	0-1	(artificial illumination)
4h test period	4/3a1/c	24	0	5/3a/c	1	(artificial illumination)	6/3a/c	0-1	(artificial illumination)
Incidur	4/3b/a	24	0	5/3b/a	1	(artificial illumination)	6/3b/a	0-1	(artificial illumination)
0) 0,75%	4/3b/b	24	0	5/3b/b	1	(artificial illumination)	6/3b/b	0-1	(artificial illumination)
1h test period	4/3b/c	24	0	5/3b/c	1	(artificial illumination)	6/3b/c	0-1	(artificial illumination)
Incidur	4/3c/a	24	0	5/3c/a	1	(artificial illumination)	6/3c/a	0-1	(artificial illumination)
3,00%	4/3c/b	24	0	5/3c/b	1	(artificial illumination)	6/3c/b	0-1	(artificial illumination)
1h test period	4/3c/c	24	0	5/3c/c	1	(artificial illumination)	6/3c/c	0-1	(artificial illumination)

Resistance of 3 "Latex" paints to 4 disinfectants at room temperature - assessment directly after the test

a) Assessmen	nt according to EN ISO 4628-1:2003(D)		
value	intensity of the change	value	intensity of the change
0	no visible change	3	medium, distinctly visible change
1	very small visible change	4	strong visible change
2	small visible change	5	very strong visible change

disinfectant	sample	assessment after [h]	Jupol Latex - Matt value	sample	F	Jupol Latex - Seidenmatt value	sample		Jupol Latex - Saten value
Kohrsolin FF	4/4a/a	at once	0	5/4a/a	1	(artificial illumination)	6/4a/a	1	(artificial illumination)
a) 0,75%	4/4a/b	at once	0	5/4a/b	1	(artificial illumination)	6/4a/b	1	(artificial illumination)
1h test period	4/4a1/c	at once	0	5/4a/c	1	(artificial illumination)	6/4a/c	1	(artificial illumination)
Kohrsolin FF	4/4b/a	at once	0	5/4b/a	1	(artificial illumination)	6/4b/a	1	(artificial illumination)
o) 1,00%	4/4b/b	at once	0	5/4b/b	1	(artificial illumination)	6/4b/b	1	(artificial illumination)
0,5h test period	4/4b/c	at once	0	5/4b/c	1	(artificial illumination)	6/4b/c	1	(artificial illumination)
Kohrsolin FF	4/4c/a	at once	0	5/4c/a	0-1	(artificial illumination)	6/4c/a	0-1	(artificial illumination)
c) 3,00%	4/4c/b	at once	0	5/4c/b	0-1	(artificial illumination)	6/4c/b	0-1	(artificial illumination)
0,5h test period	4/4c/c	at once	0	5/4c/c	0-1	(artificial illumination)	6/4c/c	0-1	(artificial illumination)

Resistance of 3 "Latex" paints to 4 disinfectants at room temperature - assessment 24 hours after the test

a) assessment	ccording to EN ISO 4628-1:2003(D)					
value	intensity of the change	value	intensity of the change			
0	no visible change	3	medium, distinctly visible change			
1	very small visible change	4	strong visible change			
2	small visible change	5	very strong visible change			

disinfectant	sample	assessment after [h]	Jupol Latex - Matt value	sample	Jupol Latex - Seidenmatt value		sample	Jupol Latex - Saten value	
Kohrsolin FF	4/4a/a	24	0	5/4a/a	1	(artificial illumination)	6/4a/a	1	(artificial illumination)
a) 0,75%	4/4a/b	24	0	5/4a/b	1	(artificial illumination)	6/4a/b	1	(artificial illumination)
1h test period	4/4a1/c	24	0	5/4a/c	1	(artificial illumination)	6/4a/c	1	(artificial illumination)
Kohrsolin FF	4/4b/a	24	0	5/4b/a	1	(artificial illumination)	6/4b/a	1	(artificial illumination)
b) 1,00%	4/4b/b	24	0	5/4b/b	1	(artificial illumination)	6/4b/b	1	(artificial illumination)
0,5h test period	4/4b/c	24	0	5/4b/c	1	(artificial illumination)	6/4b/c	1	(artificial illumination)
Kohrsolin FF	4/4c/a	24	0	5/4c/a	0	(artificial illumination)	6/4c/a	0-1	(artificial illumination)
c) 3,00%	4/4c/b	24	0	5/4c/b	0-1	(artificial illumination)	6/4c/b	0-1	(artificial illumination)
0,5h test period	4/4c/c	24	0	5/4c/c	0-1	(artificial illumination)	6/4c/c	0-1	(artificial illumination)